



Thank you for choosing CopperStillCo! Our industry leading Coppersmiths meticulously handcrafted your still.

Each still is tested, washed and polished before packing. Occasionally, there may be green residue left behind from the building and washing process. This is completely normal and is harmless. Follow the cleaning directions below to prepare your still for use:

### **\*\*Cleaning Instructions:\*\***

#### **\*\*Materials Needed:\*\***

- White Vinegar
- Salt
- Gloves
- Dish Brush OR New Toilet Brush

#### **\*\*Procedure:\*\***

1. Mix ½ cup of salt with 1 gallon of vinegar, heat to 110-115 degrees.
2. Pour the mixture into your equipment and scrub the pot, cap, worm, and thumper.
3. Rinse everything with fresh water, repeat as needed.
4. After setup, perform a "cleaning run" with 1 cup of vinegar per 5 gallons of water to clean the lines.
5. Avoid running cold water to the worm during the cleaning run to allow vapor to clean the coil.
6. Rinse everything with fresh water when completed.